

UNITY SPOTLIGHT VEHICLE APPLICATION GUIDE NO.: 168-11P (OCT 01, 2010)



MAKE	YEAR	MODEL (FOOTNOTES)	MOUNTING LOCATION	600000 CP CHROME 6 DIA HID PART NO	245000 CP *CHROME 6 DIA H3 PART NO	160000 CP *CHROME 6 DIA PART NO	100000 CP CHROME 5 DIA PART NO	100000 CP CHROME 4X6 RECT PART NO	INST KIT LH DRIVERS PART NO	INST KIT RH PASS PART NO
BUICK	2011	ENCLAVE (22)(31)	POST	340CL	330CL	325CL	250CL-H	264CL	189	----
	2011	LUCERNE (22)(31)	POST	340GM	330GM	325GM	250GM-H	264GM	244	----
CADILLAC	2011	ESCALADE ESV-LH (31)	INSIDE POST	206014	206010	206000	206002	206006	257	----
	2011	ESCALADE ESV-RH (26)(31)	INSIDE POST	206015	206011	206001	206003	206007	----	257RH
	2011	ESCALADE EXT-LH (31)	INSIDE POST	206014	206010	206000	206002	206006	257	----
	2011	ESCALADE EXT-RH (26)(31)	INSIDE POST	206015	206011	206001	206003	206007	----	257RH
	2011	ESCALADE-LH (31)	INSIDE POST	206014	206010	206000	206002	206006	257	----
	2011	ESCALADE-RH (26)(31)	INSIDE POST	206015	206011	206001	206003	206007	----	257RH
CHEVROLET	2011	AVALANCHE -LH (31)	INSIDE POST	206014	206010	206000	206002	206006	257	----
	2011	AVALANCHE W/O AIR CURTAIN	DOOR	----	330GM	325GM	250GM-H	264GM	254	254RH
	2011	AVALANCHE-RH (26)(31)	INSIDE POST	206015	206011	206001	206003	206007	----	257RH
	2011	AVEO	POST	340V	330V	325V	250V-H	264V	199	199RH
	2011	COLORADO	DOOR	----	330DC	325DC	250DC-H	264DC	254	254RH
	2011	EXPRESS-LH W/O AIR CURTAIN	INSIDE POST	97054	97050	97040	97042	97046	7441	----
	2011	EXPRESS-RH W/O AIR CURTAIN(26)	INSIDE POST	97055	97051	97041	97043	97047	----	7442
	2011	IMPALA-LH	POST	205054	205050	205040	205042	205046	256	----
	2011	IMPALA-RH	POST	205055	205051	205041	205043	205047	----	256RH
	2011	MALIBU (4)(31)	POST	3400	3300	3250	2500-H	2640	189RH	189
	2011	SILVERADO W/O AIR CURTAIN	DOOR	----	330GM	325GM	250GM-H	264GM	254	254RH
	2011	SILVERADO-LH (31)	INSIDE POST	206014	206010	206000	206002	206006	257	----
	2011	SILVERADO-RH (26)(31)	INSIDE POST	206015	206011	206001	206003	206007	----	257RH
	2011	SUBURBAN W/O AIR CURTAIN	DOOR	----	330GM	325GM	250GM-H	264GM	254	254RH
	2011	SUBURBAN-LH (31)	INSIDE POST	206014	206010	206000	206002	206006	257	----
	2011	SUBURBAN-RH (26)(31)	INSIDE POST	206015	206011	206001	206003	206007	----	257RH
	2011	TAHOE W/O AIR CURTAIN	DOOR	----	330GM	325GM	250GM-H	264GM	254	254RH
	2011	TAHOE-LH (31)	INSIDE POST	206014	206010	206000	206002	206006	257	----
	2011	TAHOE-RH (26)(31)	INSIDE POST	206015	206011	206001	206003	206007	----	257RH
	2011	TRAVERSE (4)(31)	POST	340GM	330GM	325GM	250GM-H	264GM	189RH	189
DODGE	2011	3500-5500 CHASSIS CAB (31)	POST	340CL	330CL	325CL	250CL-H	264CL	189	189RH
	2011	CHALLENGER (4)(31)	POST	340V	330V	325V	250V-H	264V	189RH	189
	2011	RAM 1500 CREW CAB (31)	POST	340CL	330CL	325CL	250CL-H	264CL	189	189RH

UNITY SPOTLIGHT VEHICLE APPLICATION GUIDE NO.: 168-11P (OCT 01, 2010)



MAKE	YEAR	MODEL (FOOTNOTES)	MOUNTING LOCATION	600000 CP CHROME 6 DIA HID PART NO	245000 CP *CHROME 6 DIA H3 PART NO	160000 CP *CHROME 6 DIA PART NO	100000 CP CHROME 5 DIA PART NO	100000 CP CHROME 4X6 RECT PART NO	INST KIT LH DRIVERS PART NO	INST KIT RH PASS PART NO
	2011	RAM 1500 QUAD CAB (31)	POST	340CL	330CL	325CL	250CL-H	264CL	189	189RH
	2011	RAM 1500 REG. CAB (31)	POST	340CL	330CL	325CL	250CL-H	264CL	189	189RH
	2011	RAM 2500-3500 PICK UP (31)	POST	340CL	330CL	325CL	250CL-H	264CL	189	189RH
FORD	2011	CROWN VICTORIA	DOOR	----	330GM	325GM	250GM-H	264GM	232	232RH
	2011	CROWN VICTORIA-LH	INSIDE POST	94016	94014	94012	94002	94006	5556	----
	2011	CROWN VICTORIA-RH	INSIDE POST	94017	94015	94013	94003	94007	----	5557
	2011	E150-350 VAN(4)(22)	POST	340P	330P	325P	250P-H	264P	29RH	----
	2011	E250-450 CUTAWAY(4)(22)	POST	340P	330P	325P	250P-H	264P	29RH	----
	2011	ESCAPE (4)(31)	POST	340GM	330GM	325GM	250GM-H	264GM	226RH	226
	2011	EXPEDITION EL-LH(31)	INSIDE POST	96034	96030	96020	96022	96026	240	----
	2011	EXPEDITION EL-RH(31)	INSIDE POST	96035	96031	96021	96023	96027	----	240RH
	2011	EXPEDITION-LH (31)	INSIDE POST	96034	96030	96020	96022	96026	240	----
	2011	EXPEDITION-RH (31)	INSIDE POST	96035	96031	96021	96023	96027	----	240RH
	2011	F150 (4)(31)	POST	340GM	330GM	325GM	250GM-H	264GM	184RH	184
	2011	F150 SUPERCAB (4)(31)	POST	340GM	330GM	325GM	250GM-H	264GM	184RH	184
	2011	F150 SUPERCREW 4DR. (4)(31)	POST	340GM	330GM	325GM	250GM-H	264GM	184RH	184
	2011	F250-F550 SUPERDUTY	DOOR	----	330V	325V	250V-H	264V	189	189RH
	2011	F650-F750 (32)	DOOR	----	330V	325V	250V-H	264V	189	189RH
	2011	MUSTANG	POST	340CL	330CL	325CL	250CL-H	264CL	189	189RH
	2011	RANGER (4)	DOOR	----	330H	325H	250H-H	264H	29RH	29
	2011	RANGER-RHD (4)	DOOR	----	330H	325H	250H-H	264H	29RH	29
	2011	TRANSIT CONNECT	SIDE ROOF	----	330GM	325GM	250GM-H	264GM	108	108RH
	2011	TRANSIT CONNECT (4)	POST	340GM	330GM	325GM	250GM-H	264GM	189RH	189
FREIGHTLINER	2011	BUSINESS CLASS M2 EXT. CAB (4)	SIDE ROOF	----	330CL	325CL	250CL-H	264CL	248RH	248
	2011	BUSINESS CLASS M2 UTILITY(4)	DOOR	----	207010	207000	207002		243RH	243
	2011	BUSINESS CLASS M2-LH (4)	DOOR	----	203030	203020	203022	203026	243RH	----
	2011	BUSINESS CLASS M2-RH (4)	DOOR	----	203031	203021	203023	203027	----	243
	2011	CASCADIA DAYCAB-LH	SIDE ROOF	----	207044	207040	207041	207042	8415	----
	2011	CASCADIA DAYCAB-RH (8)	SIDE ROOF	----	207044	207040	207041	207042	----	8415
	2011	CASCADIA SLEEPER CAB-LH	SIDE ROOF	----	207024	207020	207021	207022	8413	----
	2011	CASCADIA SLEEPER CAB-RH (8)	SIDE ROOF	----	207024	207020	207021	207022	----	8413

UNITY SPOTLIGHT VEHICLE APPLICATION GUIDE NO.: 168-11P (OCT 01, 2010)



MAKE	YEAR	MODEL (FOOTNOTES)	MOUNTING LOCATION	600000 CP CHROME 6 DIA HID PART NO	245000 CP *CHROME 6 DIA H3 PART NO	160000 CP *CHROME 6 DIA PART NO	100000 CP CHROME 5 DIA PART NO	100000 CP CHROME 4X6 RECT PART NO	INST KIT LH DRIVERS PART NO	INST KIT RH PASS PART NO
	2011	CENTURY CLASS DAYCAB (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	CENTURY CLASS DAYCAB/CONSOLE (8)	SIDE ROOF	----	330GM	325GM	250GM-H	264GM	#1	#1
	2011	CENTURY CLASS MID-ROOF-LH	SIDE ROOF	----	98010	98000	98002	98006	7615	----
	2011	CENTURY CLASS MID-ROOF-RH (8)	SIDE ROOF	----	98011	98001	98003	98007	----	7615
	2011	CENTURY CLASS RAISED ROOF-LH	SIDE ROOF	----	98010	98000	98002	98006	7615	----
	2011	CENTURY CLASS RAISED ROOF-RH (8)	SIDE ROOF	----	98011	98001	98003	98007	----	7615
	2011	CLASSIC	SIDE ROOF	----	330B	325B	250B-H	264B	52	52RH
	2011	CLASSIC RAISED ROOF (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	COLUMBIA DAYCAB (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	COLUMBIA DAYCAB/CONSOLE (8)	SIDE ROOF	----	330GM	325GM	250GM-H	264GM	#1	#1
	2011	COLUMBIA MID-ROOF-LH	SIDE ROOF	----	98010	98000	98002	98006	7615	----
	2011	COLUMBIA MID-ROOF-RH (8)	SIDE ROOF	----	98011	98001	98003	98007	----	7615
	2011	COLUMBIA RAISED ROOF-LH	SIDE ROOF	----	98010	98000	98002	98006	7615	----
	2011	COLUMBIA RAISED ROOF-RH (8)	SIDE ROOF	----	98011	98001	98003	98007	----	7615
	2011	FLD SD DAYCAB	SIDE ROOF	----	330B	325B	250B-H	264B	52	52RH
	2011	FLD SD FLAT ROOF	SIDE ROOF	----	330B	325B	250B-H	264B	52	52RH
	2011	FLD SD MID-ROOF (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	FLD SD RAISED ROOF (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	SPRINTER	POST	340GM	330GM	325GM	250GM-H	264GM	28	28RH
GMC	2011	ACADIA (4)(31)	POST	340CL	330CL	325CL	250CL-H	264CL	189RH	189
	2011	CANYON	DOOR	----	330DC	325DC	250DC-H	264DC	254	254RH
	2011	SAVANA-LH W/O AIR CURTAIN	INSIDE POST	97054	97050	97040	97042	97046	7441	----
	2011	SAVANA-RH W/O AIR CURTAIN(26)	INSIDE POST	97055	97051	97041	97043	97047	----	7442
	2011	SIERRA W/O AIR CURTAIN	DOOR	----	330GM	325GM	250GM-H	264GM	254	254RH
	2011	SIERRA-LH (31)	INSIDE POST	206014	206010	206000	206002	206006	257	----
	2011	SIERRA-RH (26)(31)	INSIDE POST	206015	206011	206001	206003	206007	----	257RH
	2011	YUKON DENALI-LH (31)	INSIDE POST	206014	206010	206000	206002	206006	257	----
	2011	YUKON DENALI-RH (26)(31)	INSIDE POST	206015	206011	206001	206003	206007	----	257RH
	2011	YUKON W/O AIR CURTAIN	DOOR	----	330GM	325GM	250GM-H	264GM	254	254RH
	2011	YUKON XL DENALI-LH (31)	INSIDE POST	206014	206010	206000	206002	206006	257	----
	2011	YUKON XL DENALI-RH (26)(31)	INSIDE POST	206015	206011	206001	206003	206007	----	257RH

UNITY SPOTLIGHT VEHICLE APPLICATION GUIDE NO.: 168-11P (OCT 01, 2010)



MAKE	YEAR	MODEL (FOOTNOTES)	MOUNTING LOCATION	600000 CP CHROME 6 DIA HID PART NO	245000 CP *CHROME 6 DIA H3 PART NO	160000 CP *CHROME 6 DIA PART NO	100000 CP CHROME 5 DIA PART NO	100000 CP CHROME 4X6 RECT PART NO	INST KIT LH DRIVERS PART NO	INST KIT RH PASS PART NO
	2011	YUKON XL W/O AIR CURTAIN	DOOR	----	330GM	325GM	250GM-H	264GM	254	254RH
	2011	YUKON XL-LH (31)	INSIDE POST	206014	206010	206000	206002	206006	257	----
	2011	YUKON XL-RH (26)(31)	INSIDE POST	206015	206011	206001	206003	206007	----	257RH
	2011	YUKON-LH (31)	INSIDE POST	206014	206010	206000	206002	206006	257	----
	2011	YUKON-RH (26)(31)	INSIDE POST	206015	206011	206001	206003	206007	----	257RH
HINO	2011	145 (15)	POST	340GM	330GM	325GM	250GM-H	264GM	50	50RH
	2011	165 (15)	POST	340GM	330GM	325GM	250GM-H	264GM	50	50RH
	2011	185 (15)	POST	340GM	330GM	325GM	250GM-H	264GM	50	50RH
	2011	238 (15)	POST	340GM	330GM	325GM	250GM-H	264GM	50	50RH
	2011	258 (15)	POST	340GM	330GM	325GM	250GM-H	264GM	50	50RH
	2011	268 (15)	POST	340GM	330GM	325GM	250GM-H	264GM	50	50RH
	2011	338 (15)	POST	340GM	330GM	325GM	250GM-H	264GM	50	50RH
HONDA	2011	FIT (22)(31)	POST	340PL	330PL	325PL	250PL-H	264PL	208	----
	2011	INSIGHT (22)(31)	POST	340GM	330GM	325GM	250GM-H	264GM	189	----
	2011	CR-V (22)(31)	POST	340O	330O	325O	250O-H	264O	199	----
	2011	CR-V-RHD (22)(31)	POST	340	330	325	250-H	264	----	199RH
	2011	RIDGELINE (4)(31)	POST	340GM	330GM	325GM	250GM-H	264GM	189RH	189
HYUNDAI	2011	GENESIS COUPE (4)(31)	POST	340O	330O	325O	250O-H	264O	189RH	189
	2011	GENESIS SEDAN (31)	POST	340CL	330CL	325CL	250CL-H	264CL	189	189RH
	2011	SANTA FE (4)(31)	POST	340O	330O	325O	250O-H	264O	184RH	184
	2011	VERACRUZ (31)	POST	340GM	330GM	325GM	250GM-H	264GM	189	189RH
INTERNATIONAL	2011	4000 SERIES-LH	DOOR	----	201050	201040	201042	201046	248	----
	2011	4000 SERIES-RH (26)	DOOR	----	201051	201041	201043	201047	----	248RH
	2011	5000i SERIES (10)	POST	340V	330V	325V	250V-H	264V	246	246RH
	2011	5000i SERIES-LH (23)	POST	----	----	----	201000	----	246	----
	2011	5000i SERIES-RH (23)	POST	----	----	----	201001	----	----	246RH
	2011	7000 SERIES-LH	DOOR	----	201050	201040	201042	201046	248	----
	2011	7000 SERIES-RH (26)	DOOR	----	201051	201041	201043	201047	----	248RH
	2011	8000 SERIES-LH	DOOR	----	201050	201040	201042	201046	248	----
	2011	8000 SERIES-RH (26)	DOOR	----	201051	201041	201043	201047	----	248RH
	2011	9000i SERIES (10)	POST	340V	330V	325V	250V-H	264V	246	246RH

UNITY SPOTLIGHT VEHICLE APPLICATION GUIDE NO.: 168-11P (OCT 01, 2010)



MAKE	YEAR	MODEL (FOOTNOTES)	MOUNTING LOCATION	600000 CP CHROME 6 DIA HID PART NO	245000 CP *CHROME 6 DIA H3 PART NO	160000 CP *CHROME 6 DIA PART NO	100000 CP CHROME 5 DIA PART NO	100000 CP CHROME 4X6 RECT PART NO	INST KIT LH DRIVERS PART NO	INST KIT RH PASS PART NO
	2011	9000i SERIES-LH (23)	POST	----	----	----	201000	----	246	----
	2011	9000i SERIES-RH (23)	POST	----	----	----	201001	----	----	246RH
	2011	CF (8)	SIDE ROOF	----	330H	325H	250H-H	264H	7634	7634
	2011	CITYSTAR (8)	SIDE ROOF	----	330H	325H	250H-H	264H	7634	7634
	2011	DURASTAR-LH	DOOR	----	201050	201040	201042	201046	248	----
	2011	DURASTAR-RH (26)	DOOR	----	201051	201041	201043	201047	----	248RH
	2011	LONESTAR-LH	DOOR	----	201050	201040	201042	201046	248	----
	2011	LONESTAR-RH (26)	DOOR	----	201051	201041	201043	201047	----	248RH
	2011	PAYSTAR-LH (23)	POST	----	----	----	201000	----	246	----
	2011	PAYSTAR-RH (23)	POST	----	----	----	201001	----	----	246RH
	2011	PROSTAR+LH	DOOR	----	201050	201040	201042	201046	248	----
	2011	PROSTAR+RH (26)	DOOR	----	201051	201041	201043	201047	----	248RH
	2011	TERRASTAR-LH	DOOR	----	201050	201040	201042	201046	248	----
	2011	TERRASTAR-RH (26)	DOOR	----	201051	201041	201043	201047	----	248RH
	2011	TRANSTAR-LH	DOOR	----	201050	201040	201042	201046	248	----
	2011	TRANSTAR-RH (26)	DOOR	----	201051	201041	201043	201047	----	248RH
	2011	WORKSTAR-LH	DOOR	----	201050	201040	201042	201046	248	----
	2011	WORKSTAR-RH (26)	DOOR	----	201051	201041	201043	201047	----	248RH
JEEP	2011	GRAND CHEROKEE (22)(31)	POST	340GM	330GM	325GM	250GM-H	264GM	189	----
KENWORTH	2011	CONV AEROCAB (T800-W900) (8)	SIDE ROOF	----	330A	325A	250A-H	264A	#1	#1
	2011	CONVENTIONAL (8)	SIDE ROOF	----	330A	325A	250A-H	264A	#1	#1
	2011	CONVENTIONAL-LH	SIDE ROOF	----	205030	205020	205022	205026	8275	----
	2011	CONVENTIONAL-RH	SIDE ROOF	----	205031	205021	205023	205027	----	8275
	2011	OFF HIGHWAY (8)	SIDE ROOF	----	330A	325A	250A-H	264A	#1	#1
	2011	T170 (8)	SIDE ROOF	----	330A	325A	250A-H	264A	#1	#1
	2011	T270 (8)	SIDE ROOF	----	330A	325A	250A-H	264A	#1	#1
	2011	T300 (8)	SIDE ROOF	----	330A	325A	250A-H	264A	#1	#1
	2011	T370 (8)	SIDE ROOF	----	330A	325A	250A-H	264A	#1	#1
	2011	T440 (8)	SIDE ROOF	----	330A	325A	250A-H	264A	#1	#1
	2011	T470 (8)	SIDE ROOF	----	330A	325A	250A-H	264A	#1	#1
	2011	T660	SIDE ROOF	----	330A	325A	250A-H	264A	108	108RH

UNITY SPOTLIGHT VEHICLE APPLICATION GUIDE NO.: 168-11P (OCT 01, 2010)



MAKE	YEAR	MODEL (FOOTNOTES)	MOUNTING LOCATION	600000 CP CHROME 6 DIA HID PART NO	245000 CP *CHROME 6 DIA H3 PART NO	160000 CP *CHROME 6 DIA PART NO	100000 CP CHROME 5 DIA PART NO	100000 CP CHROME 4X6 RECT PART NO	INST KIT LH DRIVERS PART NO	INST KIT RH PASS PART NO
	2011	T700	SIDE ROOF	----	330GM	325GM	250GM-H	264GM	108	108RH
	2011	T700-LH	SIDE ROOF	----	205010	205000	205002	205006	108	----
	2011	T700-LH POST	POST	----	201030	201020	201022	201026	245	----
	2011	T700-RH	SIDE ROOF	----	205010	205000	205002	205006	----	108RH
	2011	T700-RH POST	POST	----	201031	201021	201023	201027	----	245RH
	2011	T800 DAYCAB	SIDE ROOF	----	330A	325A	250A-H	264A	108	108RH
KIA	2011	SEDONA (22)(31)	POST	340CL	330CL	325CL	250CL-H	264CL	189	----
LINCOLN	2011	MKS (31)	POST	340CL	330CL	325CL	250CL-H	264CL	208	208RH
	2011	NAVIGATOR L-LH (31)	INSIDE POST	96034	96030	96020	96022	96026	240	----
	2011	NAVIGATOR L-RH (31)	INSIDE POST	96035	96031	96021	96023	96027	----	240RH
	2011	NAVIGATOR-LH (31)	INSIDE POST	96034	96030	96020	96022	96026	240	----
	2011	NAVIGATOR-RH (31)	INSIDE POST	96035	96031	96021	96023	96027	----	240RH
MACK	2011	GRANITE (8)(10)	SIDE ROOF	----	330V	325V	250V-H	264V	#1	#1
	2011	PINNACLE DAY FAIRING (8)(33)(36)	SIDE ROOF	----	330G	325G	250G-H	264G	7634	7634
	2011	PINNACLE DAYCAB (8)	SIDE ROOF	----	330PL	325PL	250PL-H	264PL	7634	7634
	2011	PINNACLE FLAT TOP SLEEPER (8)	SIDE ROOF	----	330PL	325PL	250PL-H	264PL	7634	7634
	2011	PINNACLE HIGH-RISE (8)(15)(36)	SIDE ROOF	----	330G	325G	250G-H	264G	#1	#1
	2011	PINNACLE MID-RISE SLEEPER (8)	SIDE ROOF	----	330PL	325PL	250PL-H	264PL	7634	7634
	2011	RAWHIDE DAYCAB (8)	SIDE ROOF	----	330PL	325PL	250PL-H	264PL	7634	7634
	2011	RAWHIDE MID-RISE SLEEPER(8)	SIDE ROOF	----	330PL	325PL	250PL-H	264PL	7634	7634
	2011	TERRA PRO CABOVER	HIGH CORNER	----	330A	325A	250A-H	264A	52	52RH
	2011	TERRA PRO LOW ENTRY (8)	SIDE ROOF	----	330H	325H	250H-H	264H	7634	7634
	2011	TITAN (8)	SIDE ROOF	----	330PL	325PL	250PL-H	264PL	7634	7634
MAZDA	2011	3 4-DOOR (31)	POST	340CL	330CL	325CL	250CL-H	264CL	189	189RH
	2011	3 5-DOOR (31)	POST	340CL	330CL	325CL	250CL-H	264CL	189	189RH
	2011	SPEED 3 (31)	POST	340CL	330CL	325CL	250CL-H	264CL	189	189RH
	2011	5 (31)	POST	340O	330O	325O	250O-H	264O	199	199RH
	2011	CX-7 (22)(31)	POST	340GM	330GM	325GM	250GM-H	264GM	199	----
	2011	CX-7-RHD (22)(31)	POST	340	330	325	250-H	264	----	199RH
	2011	CX-9 (31)	POST	340CL	330CL	325CL	250CL-H	264CL	189	189RH
MERCEDES-BENZ	2011	SPRINTER	POST	340GM	330GM	325GM	250GM-H	264GM	28	28RH

UNITY SPOTLIGHT VEHICLE APPLICATION GUIDE NO.: 168-11P (OCT 01, 2010)



MAKE	YEAR	MODEL (FOOTNOTES)	MOUNTING LOCATION	600000 CP CHROME 6 DIA HID PART NO	245000 CP *CHROME 6 DIA H3 PART NO	160000 CP *CHROME 6 DIA PART NO	100000 CP CHROME 5 DIA PART NO	100000 CP CHROME 4X6 RECT PART NO	INST KIT LH DRIVERS PART NO	INST KIT RH PASS PART NO
MITSUBISHI	2011	ENDEAVOR	POST	340GM	330GM	325GM	250GM-H	264GM	189	189RH
	2011	OUTLANDER (22)(31)	POST	340CL	330CL	325CL	250CL-H	264CL	189	----
MITSUBISHI FUSO	2011	FE SERIES (4)(15)	POST	340CL	330CL	325CL	250CL-H	264CL	25RH	25
	2011	FE SERIES CREW CAB (8)	SIDE ROOF	----	330A	325A	250A-H	264A	7634	7634
	2011	FG SERIES (4)(15)	POST	340CL	330CL	325CL	250CL-H	264CL	25RH	25
	2011	FK SERIES (11)(23)	POST	340V	330V	325V	250V-H	264V	25	25RH
	2011	FM SERIES (11)(23)	POST	340V	330V	325V	250V-H	264V	25	25RH
MOTORHOME CLASS A	2011	ALL CLASSA VEHICLES UNIV.POST(8)	POST	340H	330H	325H	250H-H	264H	#1	#1
MOTORHOME CLASS B	2011	CHEVY EXPRESS-LH W/O CURTAIN	INSIDE POST	97054	97050	97040	97042	97046	7441	----
	2011	CHEVY EXPRESS-RH W/O CURTAIN(26)	INSIDE POST	97055	97051	97041	97043	97047	----	7442
	2011	FORD E150-450 VAN CHASSIS(4)(22)	POST	340P	330P	325P	250P-H	264P	29RH	----
	2011	FREIGHTLINER SPRINTER CHASSIS	POST	340GM	330GM	325GM	250GM-H	264GM	28	28RH
	2011	GMC SAVANA-LH W/O CURTAIN	INSIDE POST	97054	97050	97040	97042	97046	7441	----
	2011	GMC SAVANA-RH W/O CURTAIN(26)	INSIDE POST	97055	97051	97041	97043	97047	----	7442
MOTORHOME CLASS C	2011	CHEVY EXPRESS-LH W/O CURTAIN	INSIDE POST	97054	97050	97040	97042	97046	7441	----
	2011	CHEVY EXPRESS-RH W/O CURTAIN(26)	INSIDE POST	97055	97051	97041	97043	97047	----	7442
	2011	FORD E150-450 VAN CHASSIS(4)(22)	POST	340P	330P	325P	250P-H	264P	29RH	----
	2011	FREIGHTLINER SPRINTER CHASSIS	POST	340GM	330GM	325GM	250GM-H	264GM	28	28RH
	2011	GMC SAVANA-LH W/O CURTAIN	INSIDE POST	97054	97050	97040	97042	97046	7441	----
	2011	GMC SAVANA-RH W/O CURTAIN(26)	INSIDE POST	97055	97051	97041	97043	97047	----	7442
NISSAN	2011	ALTIMA (31)	POST	340GM	330GM	325GM	250GM-H	264GM	189	189RH
	2011	CUBE (22)(31)	POST	340DC	330DC	325DC	250DC-H	264DC	11	----
	2011	FRONTIER CREW CAB (22)(31)	POST	340GM	330GM	325GM	250GM-H	264GM	199	----
	2011	FRONTIER KING CAB (22)(31)	POST	340GM	330GM	325GM	250GM-H	264GM	199	----
	2011	FRONTIER-RHD (22)(31)	POST	340	330	325	250-H	264	----	199RH
	2011	MURANO (31)	POST	340GM	330GM	325GM	250GM-H	264GM	189	189RH
	2011	MURANO-RHD (31)	POST	340GM	330GM	325GM	250GM-H	264GM	189	189RH
	2011	PATHFINDER (22)(31)	POST	340GM	330GM	325GM	250GM-H	264GM	199	----
	2011	PATHFINDER-RHD (22)(31)	POST	340	330	325	250-H	264	----	199RH
	2011	SENTRA (31)	POST	340GM	330GM	325GM	250GM-H	264GM	189	189RH
	2011	TITAN (31)	POST	340GM	330GM	325GM	250GM-H	264GM	199	199RH

UNITY SPOTLIGHT VEHICLE APPLICATION GUIDE NO.: 168-11P (OCT 01, 2010)



MAKE	YEAR	MODEL (FOOTNOTES)	MOUNTING LOCATION	600000 CP CHROME 6 DIA HID PART NO	245000 CP *CHROME 6 DIA H3 PART NO	160000 CP *CHROME 6 DIA PART NO	100000 CP CHROME 5 DIA PART NO	100000 CP CHROME 4X6 RECT PART NO	INST KIT LH DRIVERS PART NO	INST KIT RH PASS PART NO
	2011	VERSA (22)(31)	POST	340GM	330GM	325GM	250GM-H	264GM	189	----
	2011	VERSA-RHD (22)(31)	POST	340	330	325	250 -H	264	----	189RH
	2011	XTERRA (22)(31)	POST	340GM	330GM	325GM	250GM-H	264GM	199	----
PETERBILT	2011	CONVENTIONAL	POST	340H	330H	325H	250H-H	264H	82	82RH
	2011	CONVENTIONAL (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	CONVENTIONAL-FACTORY INSTALL-LH	SIDE ROOF	----	94052	94050	94042	94046	----	----
	2011	CONVENTIONAL-FACTORY INSTALL-RH	SIDE ROOF	----	94053	94051	94043	94047	----	----
	2011	MODEL 320 COE (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	MODEL 320 COE-FACTORY INSTALL-LH	SIDE ROOF	----	94052	94050	94042	94046	----	----
	2011	MODEL 320 COE-FACTORY INSTALL-RH	SIDE ROOF	----	94053	94051	94043	94047	----	----
	2011	MODEL 325 (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	MODEL 330 (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	MODEL 337 (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	MODEL 348 (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	MODEL 365 (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	MODEL 367 (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	MODEL 382 (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	MODEL 384 (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	MODEL 386 (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	MODEL 388 (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	MODEL 389 (8)	SIDE ROOF	----	330H	325H	250H-H	264H	#1	#1
	2011	MODEL 587-LH	POST	----	201030	201020	201022	201026	245	----
	2011	MODEL 587-RH	POST	----	201031	201021	201023	201027	----	245RH
SCION	2011	xB (22)(31)	POST	340V	330V	325V	250V-H	264V	28	----
SUBARU	2011	IMPREZA 4DR. SEDAN (31)	POST	340GM	330GM	325GM	250GM-H	264GM	208	208RH
	2011	IMPREZA 5DR. (31)	POST	340GM	330GM	325GM	250GM-H	264GM	208	208RH
	2011	IMPREZA 5DR.-RHD (31)	POST	340GM	330GM	325GM	250GM-H	264GM	208	208RH
	2011	IMPREZA OUTBACK SPORT (31)	POST	340GM	330GM	325GM	250GM-H	264GM	208	208RH
	2011	IMPREZA WRX 4DR. (31)	POST	340GM	330GM	325GM	250GM-H	264GM	208	208RH
	2011	IMPREZA WRX 5DR. (31)	POST	340GM	330GM	325GM	250GM-H	264GM	208	208RH
	2011	LEGACY (31)	POST	340GM	330GM	325GM	250GM-H	264GM	189	189RH

UNITY SPOTLIGHT VEHICLE APPLICATION GUIDE NO.: 168-11P (OCT 01, 2010)



MAKE	YEAR	MODEL (FOOTNOTES)	MOUNTING LOCATION	600000 CP CHROME 6 DIA HID PART NO	245000 CP *CHROME 6 DIA H3 PART NO	160000 CP *CHROME 6 DIA PART NO	100000 CP CHROME 5 DIA PART NO	100000 CP CHROME 4X6 RECT PART NO	INST KIT LH DRIVERS PART NO	INST KIT RH PASS PART NO
	2011	OUTBACK (31)	POST	340GM	330GM	325GM	250GM-H	264GM	189	189RH
SUZUKI	2011	EQUATOR CREW CAB(4)(31)	POST	340CL	330CL	325CL	250CL-H	264CL	253RH	253
	2011	EQUATOR EXTENDED CAB(4)(31)	POST	340CL	330CL	325CL	250CL-H	264CL	253RH	253
	2011	SX4 (31)	POST	340O	330O	325O	250O-H	264O	189	189RH
TOYOTA	2011	CAMRY (22)(31)(39)	POST	340GM	330GM	325GM	250GM-H	264GM	189	----
	2011	COROLLA MATRIX (22)(31)	POST	340CL	330CL	325CL	250CL-H	264CL	189	----
	2011	PRIUS (22)(31)	POST	340DC	330DC	325DC	250DC-H	264DC	189	----
	2011	VENZA (22)(31)	POST	340GM	330GM	325GM	250GM-H	264GM	208	----
	2011	YARIS 3DR. (31)	POST	340CL	330CL	325CL	250CL-H	264CL	208	208RH
	2011	YARIS 3DR.-RHD (31)	POST	340CL	330CL	325CL	250CL-H	264CL	208	208RH
	2011	YARIS 5DR. (31)	POST	340CL	330CL	325CL	250CL-H	264CL	208	208RH
	2011	YARIS SEDAN (31)	POST	340CL	330CL	325CL	250CL-H	264CL	208	208RH
	2011	YARIS SEDAN-RHD (31)	POST	340CL	330CL	325CL	250CL-H	264CL	208	208RH
	2011	4RUNNER (22)(31)	POST	340V	330V	325V	250V-H	264V	29	----
	2011	FJ CRUISER (4)(22)(31)	POST	340CL	330CL	325CL	250CL-H	264CL	11RH	----
	2011	LAND CRUISER (4)(22)(31)	POST	340DC	330DC	325DC	250DC-H	264DC	199RH	----
	2011	LAND CRUISER W/O AIR CURTAIN	POST	340GM	330GM	325GM	250GM-H	264GM	199	199RH
	2011	LAND CRUISER-RHD (22)(31)	POST	340	330	325	250-H	264	----	199
	2011	LAND CRUISER-RHD W/O AIR CURTAIN	POST	340GM	330GM	325GM	250GM-H	264GM	199	199RH
	2011	RAV4 W/O AIR CURTAIN (4)(22)	POST	340GM	330GM	325GM	250GM-H	264GM	189RH	----
	2011	RAV4 W/O AIR CURTAIN-RHD (22)	POST	340	330	325	250-H	264	----	189
	2011	SEQUOIA (4)(22)(31)	POST	340CL	330CL	325CL	250CL-H	264CL	208RH	----
	2011	TACOMA (4)(31)	POST	340O	330O	325O	250O-H	264O	189RH	189
	2011	TUNDRA CREWMAX (22)(31)	POST	340CL	330CL	325CL	250CL-H	264CL	189	----
	2011	TUNDRA DOUBLE CAB (22)(31)	POST	340CL	330CL	325CL	250CL-H	264CL	189	----
	2011	TUNDRA REG. CAB (22)(31)	POST	340CL	330CL	325CL	250CL-H	264CL	189	----
VOLVO	2011	VHD (15)	POST	340GM	330GM	325GM	250GM-H	264GM	79	79RH
	2011	VHD (8)(27)	SIDE ROOF	----	330V	325V	250V-H	264V	7634	7634
	2011	VN630 (15)	POST	340GM	330GM	325GM	250GM-H	264GM	79	79RH
	2011	VN630 (8)	SIDE ROOF	----	330V	325V	250V-H	264V	7634	7634
	2011	VN670 (15)	POST	340GM	330GM	325GM	250GM-H	264GM	79	79RH

UNITY SPOTLIGHT VEHICLE APPLICATION GUIDE NO.: 168-11P (OCT 01, 2010)



MAKE	YEAR	MODEL (FOOTNOTES)	MOUNTING LOCATION	600000 CP CHROME 6 DIA HID PART NO	245000 CP *CHROME 6 DIA H3 PART NO	160000 CP *CHROME 6 DIA PART NO	100000 CP CHROME 5 DIA PART NO	100000 CP CHROME 4X6 RECT PART NO	INST KIT LH DRIVERS PART NO	INST KIT RH PASS PART NO
	2011	VN670 (8)	SIDE ROOF	----	330GM	325GM	250GM-H	264GM	#1	#1
	2011	VN730 (15)	POST	340GM	330GM	325GM	250GM-H	264GM	79	79RH
	2011	VN730 (8)	SIDE ROOF	----	330GM	325GM	250GM-H	264GM	#1	#1
	2011	VN780 (15)	POST	340GM	330GM	325GM	250GM-H	264GM	79	79RH
	2011	VN780 (8)	SIDE ROOF	----	330GM	325GM	250GM-H	264GM	#1	#1
	2011	VNL DAYCAB (15)	POST	340GM	330GM	325GM	250GM-H	264GM	79	79RH
	2011	VNL DAYCAB (8)(27)	SIDE ROOF	----	330V	325V	250V-H	264V	7634	7634
	2011	VNL430 SLEEPER (15)	POST	340GM	330GM	325GM	250GM-H	264GM	79	79RH
	2011	VNL430 SLEEPER (8)(27)	SIDE ROOF	----	330V	325V	250V-H	264V	7634	7634
	2011	VNM DAYCAB (15)	POST	340GM	330GM	325GM	250GM-H	264GM	79	79RH
	2011	VNM DAYCAB (8)(27)	SIDE ROOF	----	330V	325V	250V-H	264V	7634	7634
	2011	VNM430 SLEEPER (15)	POST	340GM	330GM	325GM	250GM-H	264GM	79	79RH
	2011	VNM430 SLEEPER (8)(27)	SIDE ROOF	----	330V	325V	250V-H	264V	7634	7634
	2011	VT800 DAYCAB (15)	POST	340GM	330GM	325GM	250GM-H	264GM	79	79RH
	2011	VT800 DAYCAB (8)(27)	SIDE ROOF	----	330V	325V	250V-H	264V	7634	7634
	2011	VT830 (15)	POST	340GM	330GM	325GM	250GM-H	264GM	79	79RH
	2011	VT830 (8)	SIDE ROOF	----	330GM	325GM	250GM-H	264GM	#1	#1
	2011	VT880 (15)	POST	340GM	330GM	325GM	250GM-H	264GM	79	79RH
	2011	VT880 (8)	SIDE ROOF	----	330GM	325GM	250GM-H	264GM	#1	#1
	2011	XC90 (31)	POST	340C	330C	325C	250C-H	264C	189	189RH
	2011	XC90-RHD (31)	POST	340C	330C	325C	250C-H	264C	189	189RH
WESTERN STAR	2011	4900 SERIES	POST	340H	330H	325H	250H-H	264H	91	91RH
	2011	6900 SERIES	POST	340H	330H	325H	250H-H	264H	91	91RH
	2011	LOW/MAX	POST	340H	330H	325H	250H-H	264H	91	91RH

FOOTNOTES FOR UNITY® SPOTLIGHT APPLICATIONS

1. WHEN A VEHICLE IS ORDERED WITH THE "SPOTLIGHT PROVISION" OPTION, THE MOUNTING BRACKET(S) ARE INSTALLED AT THE FACTORY AND ALREADY ON THE CAR.
2. THE ANTENNA MUST BE FULLY EXTENDED WHEN DRILLING.
3. ON VEHICLES WITH AUTOMATIC SEATBELT SYSTEM, INNER TRIM MUST BE REMOVED ON THE "A" PILLAR BEFORE DRILLING AND WIRES OF THE AUTOMATIC SEATBELT TRACK MOVED ASIDE TO AVOID DISABLING
4. USE THE RIGHT HAND INSTALLATION KIT ON THE LEFT HAND SIDE OF THE VEHICLE.

UNITY SPOTLIGHT VEHICLE APPLICATION GUIDE NO.: 168-11P (OCT 01, 2010)



MAKE	YEAR	MODEL (FOOTNOTES)	MOUNTING LOCATION	600000 CP CHROME 6 DIA HID PART NO	245000 CP *CHROME 6 DIA H3 PART NO	160000 CP *CHROME 6 DIA PART NO	100000 CP CHROME 5 DIA PART NO	100000 CP CHROME 4X6 RECT PART NO	INST KIT LH DRIVERS PART NO	INST KIT RH PASS PART NO
------	------	-------------------	-------------------	---	---	--	---	--	--------------------------------------	--------------------------------

5. APPLICATION WORKS ON PRIOR YEAR MODELS WITH ELECTRIC REMOTE CONTROL MIRROR OPTION.
6. MUST USE "K" LENGTH SPOTLIGHT ON PASSENGER SIDE OF THE VEHICLE.
7. NO PASSENGER SIDE APPLICATION AVAILABLE. LOCATION OF GLOVE BOX INTERFERES WITH NORMAL SPOTLIGHT INSTALLATION.
8. INSTALLATION KIT MAY BE USED ON EITHER THE LEFT OR RIGHT HAND SIDE OF THE VEHICLE.
9. MUST USE "V" LENGTH SPOTLIGHT ON THE PASSENGER SIDE OF THE VEHICLE.
10. MUST ALSO ORDER SPACER #3304 TO BE INSTALLED FOR PROPER SPOTLIGHT HEAD CLEARANCE.
11. MUST ALSO ORDER SPACER #6062 TO BE INSTALLED FOR PROPER SPOTLIGHT HEAD CLEARANCE.
12. APPLICATION WILL NOT WORK ON VEHICLES EQUIPPED WITH AN EXTERIOR SUN VISOR.
13. THIS APPLICATION IS FOR VEHICLES WITHOUT ANTENNAS ONLY.
14. INSTALLATION OF SPOTLIGHT MAY INTERFERE WITH CURTAIN.
15. MUST ALSO ORDER SPACER #6462 TO BE INSTALLED FOR PROPER SPOTLIGHT HEAD CLEARANCE.
16. VACUUM HOSE MUST BE MOVED TO THE SIDE TO AVOID DAMAGE DURING DRILLING ON 4 WHEEL DRIVE MODELS.
17. EXTENDED DASH REQUIRES HANDLE IN UP POSITION. (NO LONGER APPLIES.)
18. NOT TO BE USED ON VEHICLES WITH OVERHEAD STORAGE POCKET OPTION.
19. MUST USE "C" LENGTH SPOTLIGHT ON PASSENGER SIDE OF VEHICLE.
20. 37 & 37RH NO LONGER WORK FOR VEHICLES WITHOUT DOOR MOLDING
21. NOT TO BE USED ON VEHICLES WITH DOOR MOLDINGS.
22. NO PASSENGER SIDE APPLICATION ON THIS VEHICLE.
23. USE 5" SPOTLIGHT ONLY.
24. VEHICLE IS EQUIPPED WITH ALLISON AUTOMATIC TRANSMISSION.
25. MUST USE "GM" LENGTH SPOTLIGHT ON PASSENGER SIDE OF VEHICLE
26. ON VEHICLES WITH GRAB HANDLE, HANDLE AND MOUNTING BRACKET ON POST NEED TO BE ELIMINATED FOR SPOTLIGHT INSTALLATION.
27. INTERIOR SIDE VISOR MUST EITHER BE REMOVED OR SPOTLIGHT HANDLE WILL INTERFERE WITH VISOR STOWAGE.
28. FOR VEHICLES WITH HANDLE GRIP ON THE PASSENGER SIDE POST: USE 'C' LENGTH SPOTLIGHT ON RIGHT HAND SIDE OF VEHICLE FOR PROPER CLEARANCE.
29. REQUIRES TWO (2) #10, 2 1/2" LONG SHEET METAL SCREWS FOR PROPER GROUNDING (UNITY # 7814)
30. MUST CHECK PATTERNS FOR NEW AND OLD BODY STYLES/STRUCTURES ON VEHICLE TO DETERMINE THE PROPER PATTERN FOR INSTALLATION.
31. REMOVE GARNISH TRIM TO CHECK SIDE AIR BAG LOCATION IN "A" PILLAR. DRILL SHAFT HOLE WITH CAUTION TO PREVENT AIR BAG DAMAGE.
32. MUST USE "H" LENGTH SPOTLIGHT ON THE PASSENGER SIDE OF THE VEHICLE.
33. MUST ALSO ORDER SPACER #1129 TO BE INSTALLED FOR PROPER SPOTLIGHT HEAD CLEARANCE.
34. NO TRIM AVAILABLE TO FINISH DOOR NOTCH. DEEP NOTCH, CUTS INTO HOLLOW SECTION OF DOOR. NEED BODY WORK TO FINISH DOOR NOTCH.
35. USE CAUTION WHEN DRILLING! MAINTAIN DRILL BIT FROM WALKING TOWARDS THE WINDSHIELD , OR WINDSHIELD DAMAGE MAY OCCUR. PROCEED AT YOUR OWN RISK!

UNITY SPOTLIGHT VEHICLE APPLICATION GUIDE NO.: 168-11P (OCT 01, 2010)



MAKE	YEAR	MODEL (FOOTNOTES)	MOUNTING LOCATION	600000 CP CHROME 6 DIA HID PART NO	245000 CP *CHROME 6 DIA H3 PART NO	160000 CP *CHROME 6 DIA PART NO	100000 CP CHROME 5 DIA PART NO	100000 CP CHROME 4X6 RECT PART NO	INST KIT LH DRIVERS PART NO	INST KIT RH PASS PART NO
------	------	-------------------	-------------------	---	---	--	---	--	--------------------------------------	--------------------------------

36. NEED TO CUT RELIEF HOLE IN FAIRING SO SPOTLIGHT BRACKET CAN MOUNT DIRECTLY TO SIDE ROOF.

37. 3015-96-B (3717549) MOLDED GASKET FOR ONE-FIFTY MODELS IS NO LONGER AVAILABLE.

38. RIVET-NUTS INSIDE BRACKET KITS MUST BE INSTALLED BY USING PROPER RIVET-NUT INSTALLATION TOOL. UNITY'S # 8181 TOOL IS RECOMMENDED.

39. for air curtain deployment , a 1 1/4" diameter clearance hole is needed in garnish trim around the spotlight shaft.

THE SEATBELT SYSTEM.